BEEE201L- Electronic Materials

Winter Semester 2022-23 (General Freshers)

Slot: C2+TC2

Class Id: VL2022230506506

Dr. Mallikarjuna Golla

Assistant professor

Dept. of Electrical Engineering, SELECT

Vellore Institute of Technology-Vellore Campus

✉ mallikarjuna.golla@vit.ac.in

Cabin: CBMR, 207-C

BEEE102L- Basic Electrical and Electronics Engineering


Module-2 : Semiconductor material

Dr. Mallikarjuna Golla
Assistant professor
Dept. of Electrical Engineering, SELECT
Vellore Institute of Technology-Vellore Campus

CONTENT

- Classification of semiconductor, doping of semiconductor,
- Temperature dependence, metal-semiconductor junction;
- Carrier concentration, carrier generation and recombination, carrier actions, diffusion and conduction equations, continuity equation;
- Organic semiconductor;
- Direct and indirect band gaps, optical absorption, Piezo-resistivity;
- Application of semiconductor materials: PN junction diodes, BJT, JFET, MOSFET


Introduction of Semiconductors




Atomic Structure of Copper

29 Protons, 29 Electrons

Copper valence electron easily moves from atom to atom.





Conductors: Made up of atoms, usually metals which have valence electrons that can travel easily when an electromotive force (emf voltage electrical potential) is applied.

Semiconductors: Made up of atoms that are both relatively good conductors and relatively good insulators depend on the type of conditions applied..

Insulators are materials whose electrons are held firmly to their nucleus. An insulator is a material having a high resistance which does not allow electric current to flow in it.

Why Silicon ?

⇒ At a Given temp. Ge has better conductivity than Si because of smaller Energy Gap.

→ But Si is preferred over Ge in fabrication of electronic devices, Due to 4 reasons.

1) It is easier to form SiO_2 (silicon dioxide), which make fabrication process easier.

2) Si devices can be operated over wide range of Temp (−70° to 125°C)

3) Si is available in large quantities in the form of silica (or) sand.

4) Si devices has low leakage current.

$T = 0\ K\ (-273^\circ C)$

0 eV (Conductors)

1 eV (Semiconductors) → Ge (0.785 eV) ✓, Si (1.21 eV) ✓, GaAs (1.58 eV) ✓

.6 eV (Insulators) → C (2 eV) X

Temperature with standing capability

$T(Ge) \approx 100^\circ C$

$T(Si) \approx 200^\circ C$

$*T(GaAs) \approx 200^\circ C$


Mobility of electron (μ_e): (Room temp = 27°C)


μ_e (Si) = 1300 $cm^2/V \cdot sec.$

μ_e (Ge) = 3,800 $cm^2/V \cdot sec$

μ_e (GaAs) = 8,500 $cm^2/V \cdot sec$ ✓ (High switching speed)

I_o' → Reverse Saturation (or) Leakage current :






For 1° increase in temperature, conductivity of pure germanium increases by 6% and conductivity of pure silicon increases by 8%.

Due to this, the solar panels manufactured with silicon only.

Peak Inverse Voltage (PIV) :




* PIV (Si) ≈ 1000 V

PIV (Ge) ≈ 400 V

⇒ At 'O' Kelvin a semiconductor will behaves as Insulator


⇒ At 'O' Kelvin thermal energy becomes zero, ∴ electrons cannot be excited from Valance band to conduction Band


∴ Valance Band remains Filled and conduction Band is remains empty at 0° Kelvin



⇒ If temperature is increased, then Valance electrons receives thermal energy.

If an electrons gets sufficient thermal energy ($\geq E_G$), then it will move into conduction Band and becomes free electron. At the same time a Vacancy (or) Empty Energy level will appear in VB. It is called as hole






In a semiconductor, flow of current is due to 1) movement of free electrons inside conduction band.

2) Movement of holes inside the VB, when external electric field is applied.

A hole moves because of a bound electrons move in opp. direction

⇒ Net current in semiconductor is sum of free $\bar{e}$ current and hole current.

⇒ Free electrons travel in Zig-Zag Path bcz collisions with metal ions



Mean Free time :- (Relaxation time (or) scattering)

It is the average time interval b/w two collisions.

It is denoted by $\tilde{T}_c$

Mean free Path :- (l) It is the average distance travel by electrons b/w two collisions.

Drift Velocity :- It is velocity of an electrons b/w two collisions (or) The velocity at which an electron travels during mean free time.

Momentum applied = Momentum gained

Force x time = Mass x velocity

$eE \times \tau_c = m_n \times v$

$v = \frac{e\tau_c}{m_n} \times E$

μ_n

Imp * $\boxed{v = \mu_n E}$ → Drift velocity

Where $\mu_n = \frac{e\tau_c}{m_n}$

→ Mobility of free $\bar{e}$

→ Mobility is a measure of how freely an electron is able to travel.

True Mass (m_0):- It is mass of electron in vaccum. Vaccum is the place where there is no force on electron.


$m_0 = 9.1 \times 10^{-31}$ kg

Effective Mass (m_n):- It is mass of electron in a crystal, where many forces are acting on electron.

Current Density :-

→ current per unit area

$$J = \frac{I}{A}$$



$A = \pi r^2$

n = no. of free $\bar{e}$ per unit volume

n is called concentration of free electrons (or) density of free $\bar{e}$

$$\boxed{J = nev} \quad \text{(or)} \quad \boxed{J = \rho_v v}$$


$$J = ne\mu_n E = \sigma E$$

($\sigma = ne\mu_n$)

$$\boxed{J = \sigma E}$$ ohm's law

Classification of semiconductor

Classification of semiconductor **based on purity** is mainly divided into two types 1) Intrinsic semiconductor 2) Extrinsic semiconductor.



- The process of adding impurity to a semiconductor is called doping.
- By doping of semiconductor, useful electronic devices such as diode, transistor, SCR etc…can be fabricated.
- Conductivity of semiconductor is controlled through doping. Such property is not present in metals. It has fixed conductivity.

1) Intrinsic semiconductor

- Semiconductors are tetravalent, IV_{th} group elements, having four valance electrons in the outermost of an orbit.
- Examples: Carbon (Dimond and Graphite), silicon, germanium, tin, lead and so on.


→ In a semiconductor crystal covalent bonding is present b/w semi-conductor atoms


→ Each semiconductor atoms forms four covalent bonds

→ At 0 Kelvin, all valance electrons are present inside covalent bonds

→ An electron present in covalent bond is called bound e⁻ bcz it is strongly bound b/w two parent atoms and it can not move freely when electric field is applied.

∴ semiconductor behaves as Insulator at 0 Kelvin.





→ When temp ↑, Valance electrons gets thermally energised bcz of heat

→ If a Valance electrons gets sufficient thermal energy ($\geq E_G$) then it will move outoff covalent bond in free space and becomes free electron..


→ In complete covalent bond is called hole.


→ E_G represents minimum energy needed to break covalent bond

→ If large no. of bonds are broken through thermal excitation then large no. of free electrons & holes will be produced.

→ When electric field is applied

1) Free electron travels within free space and produce free electron current.





2) Hole travels, because of movement of bound electron in opposite direction from a complete bond to incomplete bond.

This results in whole current.

$$I = I_{free\,\bar{e}} + I_{hole}$$

$$J = J_N + J_p$$

$$J = n e \mu_n E + p e \mu_p E$$

Where n: concentration of free $\bar{e}$

p: concentration of hole

μ_n, μ_p: Free $\bar{e}$ & holes Mobility

For pure semiconductor, Free $\bar{e}$ & hole concentration are equal i.e $n = p = n_i$

where n_i is called Intrinsic concentration.

$$J = n_i (\mu_n + \mu_p) e E$$

σ_i

V.Imp

$$J = \sigma_i E$$

Imp. Dominant effect

$$\sigma_i = n_i (\mu_n + \mu_p) e \quad *$$

conductivity of Intrinsic semicondu

ELECTRON AND HOLE CONCENTRATIONS

Kasap Book 5.1.4




Figure 5.7 (a) Energy band diagram. (b) Density of states (number of states per unit energy per unit volume). (c) Fermi–Dirac probability function (probability of occupancy of a state). (d) The product of $g(E)$ and $f(E)$ is the energy density of electrons in the CB (number of electrons per unit energy per unit volume). The area under $n_E(E)$ versus E is the electron concentration.

Dr.

$$n = N_c \exp\left[-\frac{(E_c - E_F)}{kT}\right] \quad [5.6]$$

Electron concentration in CB

$$N_c = 2\left(\frac{2\pi m_e^* kT}{h^2}\right)^{3/2} \quad [5.7]$$

Effective density of states at CB edge

Nc and *Nv* are effective density of states at CB edge and VB edge

h is Planck constant equal to 6.626×10^{-34} Joule seconds

k is Boltzmann constant equal to 1.38×10^{-23} J/K or 8.625×10^{-5} ev/K

Hole concentration in VB

$$p = N_v \exp\left[-\frac{(E_F - E_v)}{kT}\right] \quad [5.8]$$

Effective density of states at VB edge

where N_v is the effective density of states at the VB edge and is given by

$$N_v = 2\left(\frac{2\pi m_h^* kT}{h^2}\right)^{3/2} \quad [5.9]$$

n is the electron concentration, and p is the hole concentration.

$$np = N_c \exp\left[-\frac{(E_c - E_F)}{kT}\right] N_v \exp\left[-\frac{(E_F - E_v)}{kT}\right] = N_c N_v \exp\left[-\frac{(E_c - E_v)}{kT}\right]$$

Multiply eq. 5.6 and 5.8

$$np = N_c N_v \exp\left(-\frac{E_g}{kT}\right)$$

where $E_g = E_c - E_v$ is the bandgap energy.

In the special case of an intrinsic semiconductor, n = p, which we can denote as n_i, the **intrinsic concentration**.

$$np = n_i^2 = N_c N_v \exp\left(-\frac{E_g}{kT}\right) \quad [5.11a]$$

Mass action law

Kasap Book 5.1.

EXAMPLE 5.1 **INTRINSIC CONCENTRATION AND CONDUCTIVITY OF Si** Given that the density of states related effective masses of electrons and holes in Si are approximately $1.08m_e$ and $0.60m_e$, respectively, and the electron and hole drift mobilities at room temperature are 1400 and 450 $cm^2\ V^{-1}\ s^{-1}$, respectively, calculate the intrinsic concentration and intrinsic resistivity of Si.

SOLUTION

We simply calculate the effective density of states N_c and N_v by

$$N_c = 2\left(\frac{2\pi m_e^* kT}{h^2}\right)^{3/2} \quad \text{and} \quad N_v = 2\left(\frac{2\pi m_h^* kT}{h^2}\right)^{3/2}$$

$$PE = m.g.h$$
$$J = Kg.\frac{m}{S^2}.m$$
$$Kg.m^2.S^{-2}$$

Thus

$$N_c = 2\left[\frac{2\pi(1.08 \times 9.1 \times 10^{-31}\ \text{kg})(1.38 \times 10^{-23}\ \text{J K}^{-1})(300\ \text{K})}{(6.63 \times 10^{-34}\ \text{J s})^2}\right]^{3/2}$$
$$= 2.81 \times 10^{25}\ \text{m}^{-3} \quad \text{or} \quad 2.81 \times 10^{19}\ \text{cm}^{-3}$$

and

$$N_v = 2\left[\frac{2\pi(0.60 \times 9.1 \times 10^{-31}\ \text{kg})(1.38 \times 10^{-23}\ \text{J K}^{-1})(300\ \text{K})}{(6.63 \times 10^{-34}\ \text{J s})^2}\right]^{3/2}$$
$$= 1.16 \times 10^{25}\ \text{m}^{-3} \quad \text{or} \quad 1.16 \times 10^{19}\ \text{cm}^{-3}$$

$$n_i = (N_c N_v)^{1/2} \exp\left(-\frac{E_g}{2kT}\right)$$

Eg = 1.10eV for Si as per table

so that

$$n_i = [(2.81 \times 10^{19}\ \text{cm}^{-3})(1.16 \times 10^{19}\ \text{cm}^{-3})]^{1/2} \exp\left[-\frac{(1.10\ \text{eV})}{2(300\ \text{K})(8.62 \times 10^{-5}\ \text{eV K}^{-1})}\right]$$

$$= 1.0 \times 10^{10}\ \text{cm}^{-3}$$

The conductivity is

$$\sigma = en\mu_e + ep\mu_h = en_i(\mu_e + \mu_h)$$

$C = A.Sec$

$C = \frac{V}{\Omega}.Sec$

that is,


$$\sigma = (1.6 \times 10^{-19}\ \text{C})(1.0 \times 10^{10}\ \text{cm}^{-3})(1400 + 450\ \text{cm}^2\ \text{V}^{-1}\ \text{s}^{-1})$$

$$= 3.0 \times 10^{-6}\ \Omega^{-1}\ \text{cm}^{-1}$$

The resistivity is

$$\rho = \frac{1}{\sigma} = 3.3 \times 10^5\ \Omega\ \text{cm}$$


2) Extrinsic semiconductor.



- **Doping:-** Addition of impurity to the Pure Semiconductor at a controlled rate.
- To make the semiconductor conduct electricity, other atoms called impurities must be added. This process is called doping.
- The doped semiconductor material is called as **extrinsic semiconductor.**
- The conductivity of extrinsic semiconductor is good.


n-type semiconductor	p-type semiconductor
In n-type semiconductor pentavalent impurities are used for doping. Pentavalent impurities: Arsenic (As), Phosphorous (Pi), Antimony (Sb), etc.	In p-type semiconductor trivalent impurities are used for doping. Trivalent impurities: Aluminium (Al), Boron (B), Indium (In), Gallium (Ga), etc.
The impurity is called donor impurity.	The impurity is called acceptor impurity.
In n-type semiconductor, the electrons are majority charge carriers and holes are minority charge carriers.	In p-type semiconductor, the holes are majority charge carriers and electrons are minority charge carriers.
In n-type semiconductor, conductivity is mainly due to electrons, which are negatively charged.	In p-type semiconductor, conductivity is mainly due to holes, which are positively charged.

Atomic Structure and Crystal Lattice





Atomic Structure of Silicon

14 Protons, 14 Electrons



The unique capability of semiconductor atoms is their ability to link together to form a physical structure called a crystal lattice. These links are called **covalent bonds**.






N-type

P-type


Doped Semiconductors

1. An impurity, or element like arsenic, has 5 valence electrons.
2. Adding arsenic (doping) will allow four of the arsenic valence electrons to bond with the neighbouring silicon atoms.
3. The one electron left over for each arsenic atom becomes available to conduct current flow.



Resistance Effects of Doping

If you use lots of arsenic atoms for doping, there will be lots of extra electrons so the resistance of the material will be low and current will flow freely. If you use only a few arsenic atoms, there will be fewer free electrons so the resistance will be high and less current will flow. By controlling the doping amount, virtually any resistance can be achieved.



1. We can also dope a semiconductor material with an atom such as boron that has only 3 valence electrons.
2. The 3-electrons in the outer orbit do form covalent bonds with its neighbouring semiconductor atoms as before. But one electron is missing from the bond.
3. This place where a fourth electron should be is referred to as a hole.
4. The hole assumes a positive charge so it can attract electrons from some other source.
5. Holes become a type of current carrier like the electron to support current flow.




Figure 5.8 Energy band diagrams for (a) intrinsic, (b) *n*-type, and (c) *p*-type semiconductors. In all cases, $np = n_i^2$.

n-Type Doping

Consider what happens when small amounts of a pentavalent (valency of 5) element from Group V in the Periodic Table, such as As, P, Sb, are introduced into a pure Si crystal. We only add small amounts (*e.g.*, one impurity atom for every million host atoms) because we wish to surround each impurity atom by millions of Si atoms, thereby forcing the impurity atoms to bond with Si atoms in the same diamond crystal structure.




Figure 5.9 Arsenic-doped Si crystal.

The four valence electrons of As allow it to bond just like Si, but the fifth electron is left orbiting the As site. The energy required to release the free fifth electron into the CB is very small.

Figure 5.9. The As^+ ionic center with an electron e^- orbiting it is just like a hydrogen atom in a silicon environment. We can easily calculate how much energy is required to free this electron away from the As site, thereby ionizing the As impurity. Had this been a hydrogen atom in free space, the energy required to remove the electron from its ground state (at $n = 1$) to far away from the positive center would have been given by $-E_n$ with $n = 1$. The binding energy of the electron in the H atom is thus

$$E_b = -E_1 = \frac{m_e e^4}{8\varepsilon_o^2 h^2} = 13.6 \text{ eV}$$

If we wish to apply this to the electron around an As^+ core in the Si crystal environment, we must use $\varepsilon_r \varepsilon_o$ instead of ε_o, where ε_r is the relative permittivity of silicon, and also the effective mass of the electron m_e^* in the silicon crystal. Thus, the binding energy of the electron to the As^+ site in the Si crystal is

Electron binding energy at a donor

$$E_b^{\text{Si}} = \frac{m_e^* e^4}{8\varepsilon_r^2 \varepsilon_o^2 h^2} = (13.6 \text{ eV}) \left(\frac{m_e^*}{m_e}\right) \left(\frac{1}{\varepsilon_r^2}\right) \quad [5.15]$$

With $\varepsilon_r = 11.9$ and $m_e^* \approx \frac{1}{3} m_e$ for silicon, we find $E_b^{\text{Si}} = 0.032$ eV, which is comparable with the average thermal energy of atomic vibrations at room temperature, $\sim 3kT$ ($\sim$0.07 eV). Thus, the fifth valence electron can be readily freed by thermal vibrations of the Si lattice. The electron will then be "free" in the semiconductor,




Figure 5.10 Energy band diagram for an *n*-type Si doped with 1 ppm As.

There are donor energy levels just below E_c around As^+ sites.

If N_d is the donor atom concentration in the crystal, then provided that $N_d \gg n_i$, at room temperature the electron concentration in the CB will be nearly equal to N_d, that is $n \approx N_d$. The hole concentration will be $p = n_i^2/N_d$, which is less than the intrinsic concentration because a few of the large number of electrons in the CB recombine with holes in the VB so as to maintain $np = n_i^2$. The conductivity will then be

n-type conductivity

$$\sigma = eN_d\mu_e + e\left(\frac{n_i^2}{N_d}\right)\mu_h \approx eN_d\mu_e \qquad [5.16]$$

At low temperatures, however, not all the donors will be ionized and we need to know the probability, denoted as $f_d(E_d)$, of finding an electron in a state with energy E_d at a donor. This probability function is similar to the Fermi–Dirac function $f(E_d)$ except that it has a factor of $\frac{1}{2}$ multiplying the exponential term,

Occupation probability at a donor

$$f_d(E_d) = \frac{1}{1 + \frac{1}{2}\exp\left[\frac{(E_d - E_F)}{kT}\right]} \qquad [5.17]$$

The factor $\frac{1}{2}$ is due to the fact that the electron state at the donor can take an electron with spin either up or down but not both[4]

Thus, the concentration of ionized donors at a temperature T is given by

$$N_d^+ = N_d \times (\text{probability of not finding an electron at } E_d)$$
$$= N_d[1 - f_d(E_d)]$$
$$= \frac{N_d}{1 + 2\exp\left[\frac{(E_F - E_d)}{kT}\right]} \qquad [5.18]$$

Ionized donor concentration


If impurity atoms are added in the ratio $1:10^3$ (i.e 1 impurity for 10^3 semiconductor atoms) is called heavily doped and represented with N^+, P^+.

If impurity atoms are added in the ratio $1:10^6$ (i.e 1 impurity for 10^6 semiconductor atoms) is called moderately doped and represented with N , P .

If impurity atoms are added in the ratio $1:10^9$ (i.e 1 impurity for 10^9 semiconductor atoms) is called lightly doped and represented with N^-, P^- .

Current Flow in N-type Semiconductors

- The DC voltage source has a positive terminal that attracts the free electrons in the semiconductor and pulls them away from their atoms leaving the atoms charged positively.
- Electrons from the negative terminal of the supply enter the semiconductor material and are attracted by the positive charge of the atoms missing one of their electrons.
- Current flows from the positive terminal to the negative terminals.



Majority Carriers –Electrons

Minority Carriers -Holes

p-Type Doping




Figure 5.11 Boron-doped Si crystal.

B has only three valence electrons. When it substitutes for a Si atom, one of its bonds has an electron missing and therefore a hole, as shown in (a). The hole orbits around the B^- site by the tunneling of electrons from neighboring bonds, as shown in (b). Eventually, thermally vibrating Si atoms provide enough energy to free the hole from the B^- site into the VB, as shown.

Figure 5.11a. Because B has only three valence electrons, when it shares them with four neighboring Si atoms, one of the bonds has a missing electron, which of course is a hole. A nearby electron can tunnel into this hole and displace the hole further away from the boron atom. As the hole moves away, it gets attracted by the negative charge left behind on the boron atom and therefore takes an orbit around the B^- ion, as shown in Figure 5.11b. The binding energy of this hole to the B^- ion can be calculated using the hydrogenic atom analogy as in the *n*-type Si case. This binding energy turns out to be very small, ~0.05 eV, so at room temperature the thermal vibrations of the lattice can free the hole away from the B^- site. A free hole, we recall, exists in the VB. The escape of the hole from the B^- site involves the B atom *accepting* an electron from a neighboring Si–Si bond (from the VB), which effectively results in the hole being displaced away and its eventual escape to freedom in the VB. The B atom introduced into the Si crystal therefore acts as an electron acceptor and, because of this, it is called an **acceptor impurity.** The electron accepted by the B atom comes from a nearby bond. On the energy band diagram, an electron leaves the VB and gets accepted by a B atom, which becomes negatively charged. This process leaves a hole in the VB that is free to wander away, as illustrated in Figure 5.12.





Figure 5.12 Energy band diagram for a *p*-type Si doped with 1 ppm B. There are acceptor energy levels E_a just above E_v around B^- sites. These acceptor levels accept electrons from the VB and therefore create holes in the VB.

It is apparent that doping a silicon crystal with a trivalent impurity results in a *p*-type material. We have many more holes than electrons for electrical conduction since the negatively charged B atoms are immobile and hence cannot contribute to the conductivity. If the concentration of acceptor impurities N_a in the crystal is much greater than the intrinsic concentration n_i, then at room temperature all the acceptors would have been ionized and thus $p \approx N_a$. The electron concentration is then determined by the mass action law, $n = n_i^2/N_a$, which is much smaller than p, and consequently the conductivity is simply given by $\sigma = eN_a\mu_h$.

Current Flow in P-type Semiconductors

- Electrons from the negative supply terminal are attracted to the positive holes and fill them.
- The positive terminal of the supply pulls the electrons from the holes leaving the holes to attract more electrons.
- Current flows from the positive terminal to the negative terminal.
- Inside the semiconductor current flow is actually by the movement of the holes from positive to negative.



Majority Carriers -Holes

Minority Carriers -Electrons

Compensation Doping

Compensation doping is a term used to describe the doping of a semiconductor with both donors and acceptors to control the properties.

For example, a *p*-type semiconductor doped with N_a acceptors can be converted to an *n*-type semiconductor by simply adding donors until the concentration N_d exceeds N_a.

The electron concentration is then given by $N_d - N_a$ provided the latter is larger than n_i. When both acceptors and donors are present, what essentially happens is that electrons from donors recombine with the holes from the acceptors so that the mass action law $np = n_i^2$ is obeyed.

Remember that we cannot simultaneously increase the electron and hole concentrations because that leads to an increase in the recombination rate that returns the electron and hole concentrations to satisfy $np = n_i^2$. When an acceptor atom accepts a valence band electron, a hole is created in the VB. This hole then recombines with an electron from the CB. Suppose that we have more donors than acceptors. If we take the initial electron concentration as $n = N_d$, then the recombination between the electrons from the donors and N_a holes generated by N_a acceptors results in the electron concentration reduced by N_a to $n = N_d - N_a$. By a similar argument, if we

1. More donors: $N_d - N_a \gg n_i$ $\quad n = (N_d - N_a)$ and $p = \dfrac{n_i^2}{(N_d - N_a)}$


2. More acceptors: $N_a - N_d \gg n_i$ $\quad p = (N_a - N_d)$ and $n = \dfrac{n_i^2}{(N_a - N_d)}$

Compensation doping


Semiconductor has two types of currents i.e 1) Drift current 2) Diffusion current

1) Drift current

It flows due to presence of electric field or potential difference.
Movement of carriers due to electric field is called drift.



$$J_{drift} \alpha E$$




Electrons (n) and holes (p) drift current densities

$$J_{n,\,drift} = n\,e\,\mu_n\,E$$

$$J_{p,\,drift} = p\,e\,\mu_p\,E$$

2) Diffusion current

It flows due to presence of gradient (change) in concentration of carriers. Electrons and holes travel from higher concentration to lower concentration, because of thermal energy, which results in diffusion current.



When carriers move due to concentration gradient then such a movement is called diffusion. Diffusion current density directly proportional to concentration gradient.

$$J_{diffusion}\ \alpha\ \frac{dn}{dx}\ (or)\ \frac{dp}{dx}$$

$$J_{n,\,diffusion} = e\,D_n\,\frac{dn}{dx}$$

$$J_{n,\,diffusion} = -e\,D_p\,\frac{dp}{dx}$$

D_n , D_p are diffusion constants of electrons and holes, respectively

From Kasap Text Book, Exercise problems with solutions

EXAMPLE 5.4

EXAMPLE 5.5

EXAMPLE 5.6

TEMPERATURE DEPENDENCE OF CONDUCTIVITY

CARRIER CONCENTRATION TEMPERATURE DEPENDENCE




Figure 5.14 (a) Below T_s, the electron concentration is controlled by the ionization of the donors. (b) Between T_s and T_i, the electron concentration is equal to the concentration of donors since they would all have ionized. (c) At high temperatures, thermally generated electrons from the VB exceed the number of electrons from ionized donors and the semiconductor behaves as if intrinsic.

1. Low-temperature range ($T < T_s$). The increase in temperature at these low temperatures ionizes more and more donors. The donor ionization continues until we reach a temperature T_s, called the **saturation temperature,** when all donors have been ionized and we have saturation in the concentration of ionized donors. The electron concentration is given by Equation 5.19. This temperature range is often referred to as the **ionization range.**

2. Medium-temperature range ($T_s < T < T_i$). Since nearly all the donors have been ionized in this range, $n = N_d$. This condition remains unchanged until $T = T_i$, when n_i, which is temperature dependent, becomes equal to N_d. It is this temperature range $T_s < T < T_i$ that utilizes the *n*-type doping properties of the semiconductor in *pn* junction device applications. This temperature range is often referred to as the **extrinsic range.**

3. High-temperature range ($T > T_i$). The concentration of electrons generated by thermal excitation across the bandgap n_i is now much larger than N_d, so the electron concentration $n = n_i(T)$. Furthermore, as excitation occurs from the VB to the CB, the hole concentration $p = n$. This temperature range is referred to as the **intrinsic range.**




Figure 5.15 The temperature dependence of the electron concentration in an *n*-type semiconductor.

At low temperature

$$n = \left(\frac{1}{2}N_c N_d\right)^{1/2} \exp\left(-\frac{\Delta E}{2kT}\right) \quad [5.19]$$

$$n = (N_c N_v)^{1/2} \exp\left(-\frac{E_g}{2kT}\right) \quad [5.20]$$

At high temperature

$$n \propto T^{3/2} \exp\left(-\frac{E_g}{2kT}\right)$$

The numerical factor 1/2 in Equation 5.19 arises because donor occupation statistics is different by this factor from the usual Fermi–Dirac function, as mentioned earlier.

Nc and *Nv* are effective density of states at CB edge and VB edge

Nd and *Na* are donor and acceptor concentration

$\Delta E = Ec - Ed$

$Eg = Ec - Ev$

CONDUCTIVITY TEMPERATURE DEPENDENCE

$$\mu = \frac{e\tau}{m_e^*}$$




Figure 5.19 The variation of the drift mobility with dopant concentration in Si for electrons and holes at 300 K.




Figure 5.20 Schematic illustration of the temperature dependence of electrical conductivity for a doped (*n*-type) semiconductor.

The conductivity of an extrinsic semiconductor doped with donors depends on the electron concentration and the drift mobility, both of which have been determined above. At the lowest temperatures in the ionization range, the electron concentration depends exponentially on the temperature by virtue of

Electron concentration in ionization region

$$n = \left(\frac{1}{2}N_c N_d\right)^{1/2} \exp\left[-\frac{(E_c - E_d)}{2kT}\right]$$

which then also dominates the temperature dependence of the conductivity. In the intrinsic range at the highest temperatures, the conductivity is dominated by the temperature dependence of n_i since

$$\sigma = en_i(\mu_e + \mu_h)$$

and n_i is an exponential function of temperature in contrast to $\mu \propto T^{-3/2}$. In the extrinsic temperature range, $n = N_d$ and is constant, so the conductivity follows the temperature dependence of the drift mobility. Figure 5.20 shows schematically the semilogarithmic plot of the conductivity against the reciprocal temperature where through the extrinsic range σ exhibits a broad "S" due to the temperature dependence of the drift mobility.

Carrier Generation

It is a process of generating free electron and hole pair by providing sufficient energy to valance electron.

Carrier generation is four types

(i) Thermal Excitation
(ii) Photo Excitation
(iii) Impact Ionization
(iv) Electrical Excitation

Thermal excitation

Free electron and hole pair is created by providing thermal energy to a valance electron

Photo Excitation

When light falls on semiconductor, photons present in light by the absorption radiant energy. If a photon energy greater or equal to Eg. Then an electron gets excited from VB to CB and a pair of electron and hole is produced.


$$\text{Photon energy} \geq E_g$$

Impact Ionization

A pair of free electron and hole is produced through collision of high energy carrier with semiconductor atom .


Electrical Excitation


An electron and hole pair is produced by application of very strong electric field (V/cm)


Excited State
ΔE = hν
Photon
E = hν
e-
Excitation by photon
e-
ΔE = hν
e-
Excitation by collision

Carrier Recombination

It refers to disappears of an electron and hole pair when free electron returns from CB to VB.





Indirect recombination


Energy released in the form of heat

It occurs in Si and Ge

Direct recombination

Energy released in the form of photon (Light)

It occurs in GaAS, GaP, GaAsP


CARRIER
Recombination
Generation
electrons
holes
Energy
Energy
MEAN
LIFE TIME OF
CARRIER

Mean life time of carrier

It is the average time interval for which an electron or hole survives before recombination.

It is represented with τ_n and τ_p

Diffusion Length

It is the average distance of an electron or hole travels before recombination.

It is represented with L_n and L_p


$$L_n = \sqrt{D_n \tau_n}$$


$$L_p = \sqrt{D_p \tau_p}$$

Direct and Indirect Band Gaps


The energy of an electron is given by $E = \frac{p^2}{2m} = \frac{h^2k^2}{2m}$


Where p is momentum, m is mass of electron, h is planks constant and k is propagation constant. Thus $E \propto k^2$ which is an equation of parabola. The graph of E vs k is shown below





Maximum of VB and minimum of CB occur at same momentum values	Maximum value of VB and minimum of CB occur at two different momentum values.
The minimum of CB and maximum of VB occurring at same propagation constant (k).	The minimum of CB and maximum of VB occurring at different propagation constant (k).
Electron making transition from CB to VB, need not undergo any change in its momentum. When electron fall from CB to VB, it disappear with hole (recombination of electron and hole) and their pair release the energy in the form of Light. i.e Photon of light.	In order to make transition from minimum point in CB to maximum point in VB, the electron requires some momentum. First it will go to some defect state and then fall directly on the VB. When ever it has some deflection, it radiates the energy in the form heat in the lattice itself.
The compound semiconductor such as GaAs, GaN, GaSb, InP, InAs are direct gap semiconductor.	All elemental semiconductor such as Si, Ge, SiC, GaP are indirect gap semiconductor.
These direct gap semiconductors are used in LED and Lasers etc.	These indirect gap semiconductors are used in diodes and solar panels etc.






Carrier generation and recombination in Direct and Indirect bandgap


Junctions

- Metal-Metal Junction – Seeback effect
- Metal-Semiconductor Junction
  - Schottky junction
  - Ohmic junction
- Semiconductor-Semiconductor Junction – P-N junction

Metal-Metal Junction

Most important rule for junction is fermi level must line up at equilibrium (there is no external potential applied to the system).





Platinum(Pt) Molybdenum(Mo)

$\phi_{Pt} = 5.36\,eV > \phi_{Mo} = 4.2\,eV$

$eV_0 = \phi_{Pt} - \phi_{Mo} = 5.36 - 4.2$

$V_0 = 1.16\,eV$

Two metals come together to form a junction at equilibrium with two different work functions. In such a case, the electrons will go from low work function to high work function. This interns leads contact potential at the surface and this contact potential oppose further movement of electrons. The value of v_0 depends upon work functions of the two different material.


$v_0 \rightarrow$ Oppose the further movement of electrons


Metal-Semiconductor Junction

1. Schottky junction $\emptyset_m > \emptyset_{sem}$
2. Ohmic junction $\emptyset_m < \emptyset_{sem}$

Schottky Junction ($\phi_m > \phi_{semi}$)

Band bending goes up in the direction of Electric field.






$$eV_0 = \phi_m - \phi_{n\text{-semi}}$$

ϕ_B = Schottky barrier

$$= \phi_m - \chi_{n\text{-semi}}$$ → Electron affinity of semi-conductor


$$= (\phi_m - \phi_{n\text{-semi}}) + (E_c - E_{Fn})$$



@ Equilibrium

Applying an External Potential to Metal-Semiconductor Junction

(i) Forward Bias.



Contact potential

$= e(V_0 - V)$


V↑, barrier width ↓

e↑, I↑

$$J = J_0 \left[\exp\left(\frac{eV}{KT}\right) - 1 \right]$$

Scanned with CamScanner


[ii] Reverse bias :-



Contact Potential (barrier)
$= e(V_0 + V)$


There is a small current from metal to semi-conductor.


It's leakage current depends upon barrier (ϕ_s)



Shottky Junction
↓
Rectifier

Ohmic Junction. ($\phi_m < \phi_{semi}$)





The behaviour of this device under bias basically as a resistor. The resistance is given by n-type semiconductor.


Junction will conduct whether it is F.B (or) R.B

Conductivity determined by resistance of n-type.

anned with CamScanner

Diffusion and Conduction Equations

It flows due to presence of gradient (change) in concentration of carriers. Electrons and holes travel from higher concentration to lower concentration, because of thermal energy, which results in diffusion current.



When carriers move due to concentration gradient then such a movement is called diffusion. Diffusion current density directly proportional to concentration gradient.

$$J_{diffusion} \alpha \frac{dn}{dx} (or) \frac{dp}{dx}$$

$$J_{n,\,diffusion} = e D_n \frac{dn}{dx}$$


$$J_{p,\,diffusion} = -e D_p \frac{dp}{dx}$$

$\boldsymbol{D_n}$, $\boldsymbol{D_p}$ are diffusion constants of electrons and holes, respectively.

$$D_n = \frac{L_n^2}{\tau_n}$$

$$D_p = \frac{L_p^2}{\tau_p}$$

Mean life time of carrier (τ), Diffusion Length (L)




$$J_e = en\mu_e E_x + eD_e \frac{dn}{dx}$$


$$J_h = ep\mu_h E_x - eD_h \frac{dp}{dx}$$

$$J = en\mu_n \mathrm{E}_x + ep\mu_p \mathrm{E}_x + eD_n \frac{dn}{dx} - eD_p \frac{dp}{dx}$$

If Gradient is +ve, then $\bar{e}$ diffuse in -ve 'x' direction and resulting diffusion current will be in +ve 'x' direction.

When Gradient is +ve, then holes also diffuse in -ve 'x' direction and resulting diffusion current will also -ve 'x' direction.





Einstein Relation :-

It gives relation b/w diffusivity and mobility

IMP. $$\frac{D_n}{\mu_n} = \frac{D_p}{\mu_p} = K \times T = V_T$$

K = Boltzman constant

V_T is called Thermal voltage (or) volt equivalent of Temperature

$$V_T = K \times T = 8.6 \times 10^{-5} \times T$$

$$V_T = \frac{T}{11600}$$

Eg:- If $T = 300K$, then $V_T = 0.0258$ Volts

$V_T = 25.8$ mVolts

$= 0.0258V$


The amount of average thermal energy which an electrons gets at a tem (T) is $K \times T$ and same energy is received by electron. If a voltage of V_T volt is applied. Hence V_T is voltage equivalent of Temp (T).

the **Einstein relation,**

$$\frac{D_e}{\mu_e} = \frac{kT}{e} \quad \text{and} \quad \frac{D_h}{\mu_h} = \frac{kT}{e}$$

Continuity equation

Many semiconductor devices operate on the principle that excess charge carriers are injected into a semiconductor by external means such as illumination or an applied voltage. The injection of carriers upsets the equilibrium concentration. To determine the carrier concentration at any point at any instant we need to solve the **continuity equation,** which is based on accounting for the total charge within a small volume at that location in the semiconductor. Consider an *n*-type semiconductor slab as shown in Figure 5.34 in which the hole concentration has been upset along the *x* axis from its equilibrium value p_{no} by some external means.



Consider an infinitesimally thin elemental volume $A\ \delta x$ as in Figure 5.34 in which the instantaneous hole concentration is $p_n(x, t)$. The current density at x due to holes flowing into the volume is J_h and that due to holes flowing out at $x + \delta x$ is $J_h + \delta J_h$. There is a change in the hole current density J_h; that is, $J_h(x, t)$ is not uniform along x. (Recall that the total current will also have a component due to electrons.) We assume that $J_h(x, t)$ and $p_n(x, t)$ do not change across the cross section along the y or z directions. If δJ_h is *negative*, then the current leaving the volume is less than that entering the volume, which leads to an increase in the hole concentration in $A\ \delta x$. Thus,

$$\frac{1}{A\ \delta x}\left(\frac{-A\ \delta J_h}{e}\right) = \begin{array}{c}\text{Rate of increase in hole concentration} \\ \text{due to the change in } J_h\end{array} \qquad [5.43]$$

The negative sign ensures that negative δJ_h leads to an increase in p_n. Recombination taking place in $A\ \delta x$ removes holes from this volume. In addition, there may also be photogeneration at x at time t. Thus,


The *net* rate of increase in the hole concentration p_n in $A\ \delta x$
= Rate of increase due to decrease in J_h − Rate of recombination + Rate of photogeneration

Continuity equation for holes

$$\frac{\partial p_n}{\partial t} = -\frac{1}{e}\left(\frac{\partial J_h}{\partial x}\right) - \frac{p_n - p_{no}}{\tau_h} + G_{\text{ph}} \qquad [5.44]$$

https://www.youtube.com/watch?v=OA36C-JehFI


CONTINUITY EQUATION



$$\frac{\partial n}{\partial t} A \Delta x = \frac{J_n(x) A}{-q \Delta x} - \frac{J(x+\Delta x) A}{-q \Delta x} + G_n A \Delta x - R_n A \Delta x$$

- $\frac{\partial n}{\partial t}$: no. of e⁻s ↑ w.r.t in Box
- $\frac{J_n(x) A}{-q \Delta x}$: no. of e⁻s flowing in to the Box
- $\frac{J(x+\Delta x) A}{-q \Delta x}$: no. of e⁻s flowing out of the Box
- $G_n A \Delta x$: no. of e⁻s generated in the Box
- $R_n A \Delta x$: no. of e⁻s recomb in the Box

A Δx



Lim $\Delta x \to 0$

$$\frac{\partial n}{\partial t} = \frac{1}{q}\left[\frac{J_n(x+\Delta x,t) - J_n(x,t)}{\Delta x}\right] + G_n - R_n$$


$$\boxed{\frac{\partial n}{\partial t} = \frac{1}{q}\frac{\partial J_n}{\partial x} + G_n - R_n}$$

$$\boxed{\frac{\partial p}{\partial t} = -\frac{1}{q}\frac{\partial J_p}{\partial x} + G_p - R_p}$$

$$J_n = J_{n\,drift} + J_{n\,diff} = q n \mu_n E + q D_n \frac{\partial n}{\partial x}$$

$$J_p = J_{p\,drift} + J_{p\,diff} = q p \mu_p E + -q D_p \frac{\partial p}{\partial x}$$


CONTINUITY EQUATION



$$\frac{\partial n}{\partial t} A \Delta x = \frac{J_n(x) A}{-q \Delta x} - \frac{J(x+\Delta x) A}{-q \Delta x} + G_n A \Delta x - R_n A \Delta x$$

- $\frac{\partial n}{\partial t} A \Delta x$: no. of e⁻s ↑ w.r.t in Box
- $\frac{J_n(x) A}{-q \Delta x}$: no. of e⁻s flowing in to the Box
- $\frac{J(x+\Delta x) A}{-q \Delta x}$: no. of e⁻s flowing out of the Box
- $G_n A \Delta x$: no. of e⁻s generated in the Box
- $R_n A \Delta x$: no. of e⁻s recomb in the Box

A Δx



$\lim_{\Delta x \to 0}$

$$\frac{\partial n}{\partial t} = \frac{1}{q}\left[\frac{J_n(x+\Delta x,t) - J_n(x,t)}{\Delta x}\right] + G_n - R_n$$

$$\frac{\partial n}{\partial t} = \frac{1}{q}\frac{\partial J_n}{\partial x} + G_n - R_n$$

$$\frac{\partial p}{\partial t} = -\frac{1}{q}\frac{\partial J_p}{\partial x} + G_p - R_p$$

$$\frac{\partial n}{\partial t} = n\mu_n \frac{\partial E}{\partial x} + \mu_n E \frac{\partial n}{\partial x} + D_n \frac{\partial^2 n}{\partial x^2} + G_n - R_n$$

$$\frac{\partial p}{\partial t} = -p\mu_p \frac{\partial E}{\partial x} - \mu_p E \frac{\partial p}{\partial x} + D_p \frac{\partial^2 p}{\partial x^2} + G_p - R_p$$

Optical Absorption

Optical absorption means the absorption of electromagnetic radiations of light by semiconductor materials.

We have already seen that a photon of energy *hf* greater than E_g can be absorbed in a semiconductor, resulting in the excitation of an electron from the valence band to the conduction band, as illustrated in Figure 5.36.

The average energy of electrons in the conduction band is 3/2 *kT* above *Ec* (average kinetic energy is 3/2 *kT*), which means that the electrons are very close to *Ec*.

If the photon energy is much larger than the bandgap energy E_g, then the excited electron is not near E_c and has to lose the extra energy $hf - E_g$ to reach thermal equilibrium.






Figure 5.36 Optical absorption generates electron–hole pairs.

Energetic electrons must lose their excess energy to lattice vibrations until their average energy is $\frac{3}{2}kT$ in the CB.

The excess energy $hf - E_g$ is lost to lattice vibrations as heat as the electron is scattered from one atomic vibration to another. This process is called **thermalization.**

If, on the other hand, the photon energy *hf* is less than the bandgap energy, the photon will not be absorbed and we can say that the semiconductor is transparent to wavelengths longer than hc/E_g provided that there are no energy states in the bandgap. There, of course, will be reflections occurring at the air/semiconductor surface due to the change in the refractive index.





Suppose that I_o is the intensity of a beam of photons incident on a semiconductor material. Thus, I_o is the energy incident per unit area per unit time.

Consequently, absorption depends on the thickness of the semiconductor. Suppose that $I(x)$ is the light intensity at x and δI is the change in the light intensity in the small elemental volume of thickness δx at x due to photon absorption,

as illustrated in Figure 5.37. Then δI will depend on the number of photons arriving at this volume $I(x)$ and the thickness δx. Thus

$$\delta I = -\alpha I \, \delta x$$

where α is a proportionality constant that depends on the photon energy and hence wavelength, that is, $\alpha = \alpha(\lambda)$. The negative sign ensures that δI is a reduction. The constant α as defined by this equation is called the **absorption coefficient** of the semiconductor. It is therefore defined by

$$\alpha = -\frac{\delta I}{I \, \delta x} \qquad [5.60]$$

which has the dimensions of length^{-1} (m^{-1}).

When we integrate Equation 5.60 for illumination with a constant wavelength light, we get the **Beer–Lambert law,** the transmitted intensity decreases exponentially with the thickness,

$$I(x) = I_o \exp(-\alpha x) \qquad [5.61]$$

Piezo-resistivity


Piezo-resistivity is an electromechanical phenomenon in which the electrical resistivity of a material changes reversibly with strain.

Stress – Force per unit area

Strain – Deflection per unit length/area

Applications: Variety of Sensors such as Force, strain, pressure and bio-medical instruments.

The change in the resistivity may be due to a change in the concentration of carriers or due to a change in the drift mobility of the carriers, both of **which can be modified by a strain** in the crystal. Typically, in an extrinsic or doped semiconductor, the concentration of carriers does not change as significantly as the drift mobility; the piezoresistivity is then associated with the change in the mobility.






Figure 5.39 Piezoresistivity and its applications. (a) Stress σ_m along the current (longitudinal) direction changes the resistivity by $\delta\rho$. (b) Stresses σ_L and σ_T cause a resistivity change. (c) A force applied to a cantilever bends it. A piezoresistor at the support end (where the stress is large) measures the stress, which is proportional to the force. (d) A pressure sensor has four piezoresistors R_1, R_2, R_3, R_4 embedded in a diaphragm. The pressure bends the diaphragm, which generates stresses that are sensed by the four piezoresistors.

Dr. M

Organic semiconductor

Organic semiconductors are solids whose building blocks are pi-bonded molecules or polymers made up by carbon and hydrogen atoms and – at times – heteroatoms such as nitrogen, sulfur and oxygen. They exist in the form of molecular crystals or amorphous thin films.

In general, they are electrical insulators, but become semiconducting when charges are either injected from appropriate electrodes, upon doping or by photoexcitation.

Inorganic vs Organic

In inorganic semiconductors as Si or Ge, atoms are bond together by very strong covalent bonds. Electrons and holes can freely move within aperiodic structure **(m_{eff}).** Charge carriers can be considered as delocalized planar waves very high mobility

- Perfect crystal structure
- continuous bands
- Scattering limited:

Impurities

Phonons

- **Mobility decreases with Temperature**

- Very low molecular crystal degree: polycrystalline or amorphous films.
- Randomly oriented molecules that interacts with very small forces*(Van Der Waals).*
- Charge carriers, free mean path could be smaller that interatomic distance!
- Worse delocalization, charge carriers moves through localized energetic states **(Hopping).**
  - No crystal structure
  - Discrete energetic levels
  - Phonon assisted transport
  - Mobility increases with temperature, thermal activation

There are different doping approaches:
Chemical doping
Electrochemical doping
Photo-induced doping
Charge injection doping



Practice makes you perfect


Solve the exercise Problems from text books (Kasap and Donald Neamen)

CONTENT


- Classification of semiconductor, doping of semiconductor,
- Temperature dependence, metal-semiconductor junction;
- Carrier concentration, carrier generation and recombination, carrier actions, diffusion and conduction equations, continuity equation;
- Organic semiconductor;
- Direct and indirect band gaps, optical absorption, Piezo-resistivity;
- Application of semiconductor materials: PN junction diodes, BJT, JFET, MOSFET

Application of semiconductor materials:


P-N Junction Diode




P-N junction representation




Schematic symbol




Real component appearance






- A piece of semiconductor material, if one half is doped by P-type and the other half is doped by N-type impurity, a P-N junction is formed.
- The plane dividing the two half's or zones is called PN junction.
- The N-type has high concentration of free electron while P type has high concentration of holes. Therefore at the junction there is tendency of the free electrons to diffuse over to the P-side and holes to the N-side (This process is called diffusion).
- The net opposite charge in each layer prevents it for the diffusion into that layer.
- The bearing is set up near the junction which prevent further moment of charge carriers. This is called a potential barrier (0.3V for Germanium and 0.7 for Silicon).




Diode Operating Conditions


- ✓ **No bias**
- ✓ **Forward bias**
- ✓ **Reverse bias**


Forward bias





Forward current in a diode






- When positive terminal of battery is connected to the P-type and negative terminal to the N-type of the PN junction diode, the bias applied is known as forward bias.
- The applied positive potential repels the holes in the P-type region so that the holes move towards the junction and the applied negative potential repels the electrons in the N-type region and the electrons move towards the junction (When applied voltage V_F is less than internal barrier V_0) and hence the forward current I_F is almost zero.
- Eventually when the applied potential is more than the internal barrier (V_0) potential the barrier will disappear.
- Hence, the holes cross the junction from P-type to N-type and the electrons cross the junction in the opposite direction resulting in relatively large current flow in the external circuit.

Reverse bias

- When the negative terminal of the battery is connected to the P-type and positive terminal is connected to N-type of the PN junction, the bias applied is known as reverse bias.
- Under this condition, holes form the majority carriers of P-side move towards the negative terminal of the battery and electrons which form the majority carriers of the N-side are attracted towards the positive terminal of the battery.




- Hence the width of the depletion region which is depleted of mobile carriers increases.
- Thus the electric filed produced by applied reverse bias is in the same direction of electric field and hence the barrier is increased.
- Therefore, theoretically no current should flow in the external circuit.
- But in practice very small reverse current in the order of microamperes flows under bias. This current is called as reverse saturation current.

- The magnitude of reverse saturation current mainly depends upon junction temperature because the major source of minority carriers is thermally broken covalent bonds.

For large reverse bias is applied,

- The free electrons from the N-type moving towards the positive terminal of the battery acquire sufficient energy to move with high velocity to dislodge valence electrons from semiconductor atom in the crystal.
- Thus large number of free electrons are formed which is commonly called as avalanche of free electrons. This leads to the break down of junction leading to very large reverse current. The reverse voltage at which the junction break down is known as breakdown voltage.

V-I Characteristics




Applications


- PN junction diode is used as a more triple, voltage doubler and quadruples in voltage multiplier circuit.
- They are used as a switch in many electronics circuits.
- They are used in power supply.
- This diode can be used by many circuits **rectifiers**, varactor for voltage-controlled oscillators.
- While PN junction diode produced light when biased with a current, so it is used in light emitting diode applications.
- This diode can be also used for another diode called a light amplification stimulation emission of radiation.
- In power electronics engineering, it can be used in solar cells.
- It can be used as a detector for the demodulation circuit.
- In digital electronics, this diode can be used as switches in digital logic design.
- This diode can be used as a rectifier in the DC power supply.
- While we are using the clipping circuit, this diode can be used to clip the portion of AC.
- They are used as clamper to change the reference voltage.
- Zener diode most commonly used in stabilizing circuits.
- It can be used as a varactor diode for use in the voltage-controlled tuning circuit as may be found in radio and TV receivers.
- The voltage across the PN junction biased is used to create temperature sensors and reference voltages.
- This diode can be used as voltage multipliers to increase the output voltage.
- It can be used as a signal diode in communication circuits.
- These diodes must be used in various daily life applications like computers, radios, radars as wave shaping circuits.
- It is used in many circuits or diode-like, a switching diode, Zener diode, PIN photo-diode, varactor diode.

Bipolar Junction Transistor (BJT)











A Bipolar Junction Transistor (BJT) is a type of transistor that uses both electron and hole charge carriers. In contrast, unipolar transistors, such as filed-effect transistors, only use one kind of charge carrier for their operation.

- A Bipolar Junction Transistor (BJT) is a three terminal semiconductor device in which the operation depends on the interaction of both majority and minority carriers and hence the name Bipolar.
- BJT is used as a linear amplifier to boost an electrical signal and as an electronic switch.
- BJT is formed by adding a second **p** or **n** region to a **pn** junction diode.
- With two **n** regions and one **p** region, two junctions are formed and it is known as an **NPN-transistor.**
- With two **p** regions and one **n** region, it is called as **PNP-transistor.**
- **The** three terminals are named as **Collector (C), Emitter (E) and Base (B).**
- A bipolar transistor has two junctions, collector base junction(CBJ) and base-emitter junction(BEJ)




(a) NPN Transistor



(b) PNP Transistor

Properties of Emitter Base and Collector


- **Emitter---** It is heavily doped than any of the other regions because its main function is to supply majority charge carries (either electrons or holes) to the base.
- **Base---** It forms the middle section of the transistor. It is very thin as compared to either the emitter or collector and is very ***lightly doped.***
- **Collector---** Its main function (as indicated by its name) is to collect majority charge carriers coming from the emitter and passing through the base.



In most transistors, collector region is made physically larger than the emitter region because it has to dissipate much greater power. Because of this difference, there is no possibility of inverting the transistor i.e. making its collector the emitter and its emitter the collector.

The **arrow-head is always on the emitter** (not at the collector) and in each case, its direction indicates the conventional direction of current flow.

- For a PNP transistor, arrowhead points from emitter to base meaning that emitter is positive with respect to base (and also with respect to collector).
- For NPN transistor, it points from base to emitter meaning that base (and collector as well)* is positive with respect to the emitter





Transistor Biasing


For proper working of a transistor, it is essential to apply voltages of correct polarity across its two junctions (CBJ and EBJ).

No.	Emitter-base junction	Collector-base junction	Region of operation	Uses
I	FB	RB	Active	Amplifiers
II	FB	FB	Saturation	Switching circuits
III	RB	RB	Cut-off	
IV	RB	FB	Inverse	Hardly used

Emitter-base junction is always forward biased and Collector-base junction is always reverse-biased








n p n

$I_E = I_B + I_C$




p n p


$I_E = I_B + I_C$


The three primary currents which flow in a properly-biased transistor are I_E, I_B, *and* I_C

It means that a small part (about 1—2%) of emitter current goes to supply base current and the remaining major part (98—99%) goes to supply collector current. (PNP)

Operation of NPN transistor









- The forward bias applied to the emitter base junction of an NPN transistor causes a lot of electrons from the emitter region to crossover to the base region.
- As the base is lightly doped with P-type impurity, the number of holes in the base region is very small and hence the number of electrons that combine with holes in the P-type base region is also very small. Hence a few electron combine with holes to constitute a base current I_B .
- The remaining electrons (more than 95%) crossover into the collector region to constitute a collector current I_C.
- Thus the base and collector current summed up gives the emitter current, i.e. $\boldsymbol{I_E = I_B + I_C}$


Transistor Circuit Configurations


- Basically, there are three types of circuit connections (called configurations) for operating a transistor.
  - **Common-base (*CB*),**
  - **Common-emitter (*CE*),**
  - **Common-collector (*CC*).**
- The term 'common' is used to denote the electrode that is common to the input and output circuits.
- Because the common electrode is generally grounded, these modes of operation are frequently referred to as grounded-base, grounded emitter and grounded-collector configurations.
- Since a transistor is a 3-terminal (and not a 4-terminal) device, one of its terminals has to be common to the input and output circuits.







Common-Emitter (CE) configuration





Common-Collector (CB) configuration






Common-Base (CB) configuration


CE Configuration

Voltage gain, current gain and power gain of a common emitter configuration is high when compared to other transistor configurations.



CE Configuration


- It shows how I_B varies with changes in V_{BE} when V_{CE} is held constant at a particular value.
- Steps:
  - Voltage V_{CE} is maintained constant at a convenient value and then V_{BE} is increased in steps. Corresponding values of I_B are noted at each step.
  - The procedure is then repeated for a different but constant value of V_{CE}.



Input characteristics

CE Configuration

Output characteristics



- It indicates the way in which I_C varies with changes in V_{CE} when I_B is held constant.
- Steps:
  - first I_B is set to a convenient value and maintained constant and then V_{CE} is increased from zero in steps, I_C being noted at each step.
  - Next, V_{CE} is reduced to zero and I_B increased to another convenient value and the whole procedure repeated.
  - In this way, a family of curves is obtained as shown.

Active Region

In the active region of a common-emitter amplifier the collector-base junction is reverse-biased, while the base-emitter junction is forward-biased. The active region of the common-emitter configuration can be employed for voltage, current, or power amplification.

Cut-off Region

Here the operating conditions of the transistor are zero input base current (I_B), zero output collector current (I_C) and maximum collector voltage (V_{CE}) which results in a large depletion layer and no current flowing through the device. Therefore the transistor switched "Fully-OFF".

Saturation Region

Here the transistor will be biased so that the maximum amount of base current is applied, resulting in maximum collector current resulting in the minimum collector emitter voltage drop which results in the depletion layer being as small as possible and maximum current flowing through the transistor. Therefore the transistor is switched "Fully-ON".

Transistor terms and formulas

- The current flowing out of the transistor must be equal to the currents flowing into the transistor as the emitter current is given as

$$I_E = I_B + I_C$$

- The ratio of the collector current to the emitter current is called alpha (α) of a transistor.

$$\alpha = \frac{I_C}{I_E}$$

- The α of a transistor is a measure of the quality of a transistor; higher the value of α, better the transistor in the sense that collector current more closely equals the emitter current. Its value ranges from 0.95 to 0.999.
- The load resistance (R_L) is connected in series with the collector, the current gain of the common emitter transistor configuration is quite large.
- Note: that the value of Alpha will always be less than unity.

- The ratio of the collector current to base current is called beta (β) of the transistor.

$$\beta = \frac{I_C}{I_B}$$

- It is possible for β to have as high a value as 500.
- Relation Between α and β

$$\frac{\beta}{\alpha} = \frac{I_E}{I_B} \qquad I_E = I_B + I_C = \frac{I_C}{\alpha} \qquad I_B = I_C\left(1 - \frac{1}{\alpha}\right)$$

$$\beta = \frac{I_C}{I_B} = \frac{\alpha}{1-\alpha} \qquad \beta = \frac{\alpha}{1-\alpha}$$


$$\alpha = \frac{I_C}{I_E} \quad , \qquad \beta = \frac{I_C}{I_B} \quad , \qquad \alpha = \frac{\beta}{(1+\beta)} \text{ and } \beta = \frac{\alpha}{(1-\alpha)}$$

$$I_C = \beta I_B = \alpha I_E = \frac{\beta}{1+\beta} I_E$$

$$I_B = \frac{I_C}{\beta} = \frac{I_E}{1+\beta} = (1-\alpha) I_E$$


$$I_E = \frac{I_C}{\alpha} = \frac{1+\beta}{\beta} I_C = (1+\beta)\, I_B = \frac{I_B}{(1-\alpha)}$$


Field Effect Transistor (FET)




Junction Field Effect Transistor (JFET)

- A moderately doped semiconductor used as channel.
- One end of the channel is called drain (D) and other end is called Source (S).
- Carriers travel through channel from source to drain, which results flow of drain current.
- **Source:** It is the terminal through which majority carriers enter channel.
- **Drain:** It is the terminal through which majority carriers leaves or exit the channel.
- Two heavily doped P+ regions are formed in n-type channel. These P+ regions are internally shorted to each other and they are acts as gate regions.















Figure 6.55 (a) The basic structure of the junction field effect transistor (JFET) with an *n*-channel. The two p^+ regions are electrically connected and form the gate. (b) A simplified sketch of the cross section of a more practical *n*-channel JFET.



$V_{GS} = 0$
p+
I_D
S
$+V_{DS}$
p+
$V_{GS} = 0$


$V_{GS} = 0$
I_D
V_{DS}


$V_{GS} = -V_1$
p+
I_D
S
$+V_{DS}$
p+
$V_{GS} = -V_1$


$V_{GS} = 0$
$V_{GS} = -V_1$
I_D
V_{DS}


$V_{GS} = -V_2$
p+
I_D
S
$+V_{DS}$
p+
$V_{GS} = -V_2$


$V_{GS} = 0$
$V_{GS} = -V_1$
I_D
$V_{GS} = -V_2$
V_{DS}





Figure 6.57 Typical I_D versus V_{DS} characteristics of a JFET for various fixed gate voltages V_{GS}.

Metal Oxide Semiconductor Field Effect Transistor (MOSFET)


- The primary difference between the two types of transistors is the fact that the **BJT transistor is a current-controlled device** while **MOSFET is a voltage-controlled device.**

- The MOSFET is a unipolar device depending solely on either electron (n-channel) or hole (p-channel) conduction.
- It is a 4 terminal device namely Drain (D), Source (S), Substrate (Body), and Gate (G).
- The Drain and Source terminals are connected to heavily doped regions.
- The gate terminal is connected to the oxide layer.
- The body of the MOSFET is frequently connected to the source terminal so making it a three terminal device like BJT.




- P- ch = P- channel
- N- ch = N- channel


Enhancement MOSFET (n-type)




N and P Channel MOSFET




N-channel MOSFET




P-channel MOSFET






- The MOSFET works by electronically varying the width of a channel along which charge carriers flow (electrons or holes).
- The charge carriers enter the channel at source and exit via the drain.
- The width of the channel is controlled by the voltage on an electrode is called gate which is located between source and drain.
- It is insulated from the channel near an extremely thin layer of metal oxide.





N-channel MOSFET

- If the MOSFET is an n-channel or nMOS FET, then the source and drain are heavily doped 'n' regions and the body is a 'p' region.
- If the MOSFET is a p-channel or pMOS FET, then the source and drain are heavily doped 'p' regions and the body is a 'n' region




P-channel MOSFET


Source(S)
Drain(D)
n
n
p
Forward Biased
Reverse Biased
u.com



S
G
D
n
n
ical4u.com

- Enhancement-type MOSFETS are MOSFETs that are normally off.
- When you connect an enhancement-type MOSFET, no current flows from drain to source when no voltage is applied to its gate.
- This is why it is called a normally off device. There is no current flow without a gate voltage.
- However, if a voltage is applied to the gate lead of the MOSFET, the drain source channel becomes less resistive. As the gate-source voltage increases more and more, the current flowing from drain to source increases more and more, until maximum current is flowing from drain to source.
- An enhancement-type MOSFET is so named an enhancement device, because as the voltage to the gate increases, the current increases more and more, until at maximum level.
- An enhancement-type MOSFET behaves very similar in action to a bipolar junction transistor.

Enhancement p-channel MOSFET



Enhancement n-channel MOSFET



Applications of MOSFET

- MOSFET amplifiers are extensively used in radio frequency applications.
- It acts as a passive element like resistor, capacitor and inductor.
- High switching speed of MOSFETs make it an ideal choice in designing chopper circuits.


Advantages of MOSFET

- MOSFETs provide greater efficiency while operating at lower voltages.
- Absence of gate current results in high input impedance producing high switching speed.
- They operate at lower power and draws no current.

Disadvantages of MOSFET

- The thin oxide layer make the MOSFETs vulnerable to permanent damage when evoked by electrostatic charges.
- Overload voltages makes it unstable.

Properties of Semiconductor devices for Power Converters:



Traditional Si device:

▶ Silicon (Si):

- ✦ Widely available and inexpensive.
- ✦ Has a lower bandgap energy compared to SiC and GaN.
- ✦ Lower electron mobility.
- ✦ Can handle lower temperatures and power densities.

Wide Bandgap devices:

▶ Silicon Carbide (SiC):

- ✦ Wide bandgap semiconductor.
- ✦ High thermal conductivity.
- ✦ Excellent high-temperature performance.
- ✦ Suitable for high-power and high-temperature applications.
- ✦ Requires more complex manufacturing processes.

▶ Gallium Nitride (GaN):

- ✦ Wide bandgap material.
- ✦ High electron mobility.
- ✦ High-frequency operation.
- ✦ Suitable for high-frequency and high-power-density applications.
- ✦ Typically operates at lower temperatures compared to SiC.

Properties:

🚀 Switching Speed:

GaN switches have a faster switching speed compared to both SiC and Si. This makes them ideal for high-frequency applications, such as radio frequency (RF) and power supplies.

⚡ Power Density:

SiC and GaN can handle higher power densities than traditional silicon-based switches. They are better suited for applications requiring high power output, such as electric vehicles and renewable energy inverters.

🔋Efficiency:

SiC and GaN switches offer higher efficiency, especially at high operating frequencies. This can lead to reduced power loss and increased energy savings.

Thermal Performance:

SiC has excellent thermal conductivity, making it more suitable for high-temperature applications compared to Si and GaN. GaN can handle moderately high temperatures but is not as thermally conductive as SiC.

💰Cost:

Silicon is the most cost-effective material due to its wide availability and established manufacturing processes.

SiC and GaN are typically more expensive, but their cost-effectiveness can be justified in specific applications where their unique properties provide significant advantages.

🏭 Application Areas:

Silicon is commonly used in low to medium-power applications.

SiC is favored in high-power and high-temperature applications, such as electric vehicle inverters and high-voltage power supplies.

GaN is often used in high-frequency, high-power-density applications, such as RF amplifiers and fast chargers.


Thank You!